


Q What is “Declutter” feature ?

A Declutter feature is used when page Zoom level is changed. If user specifies a custom zoom level on Object, this object is displayed at the predefined zoom level or higher only.

- At “auto” mode of CIMON-X,
Object is displayed only when the current page zoom level is the same as the predefined level or higher.
- At “manual” mode of CIMON-X,
Object is displayed at the predefined page zoom level.
- ※ To set a default declutter setting on CIMON-X, go to [View] → [Declutter].



< Declutter on CIMON-D >